

PRISCO[®] SALT CRYSTAL REMOVER & ALKALINE PAPER ROLLER RINSE



Product Description: These products remove calcium carbonate as well as other salt buildups and glazes on press rollers. The products will keep rollers cleaner, prevent roller stripping and promote more consistent color.

PRISCO Salt Crystal Remover is intended for deep cleaning when there is a visible calcium build-up and as the first step of a total maintenance program.

PRISCO Alkaline Paper Roller Rinse is intended for regular follow-up use.

Advantages:

- · Prevents calcium salt build-up and roller glazing
- No offensive odor
- · Far more effective than most similar cleaners

Directions: For thorough cleaning, **PRISCO Salt Crystal Remover** is usually best applied by hand to rollers removed from the press. It may also be applied to localized areas of rollers on press, as needed, after regular maintenance.

To use **PRISCO Alkaline Paper Roller Rinse**, wash-up rollers as usual. When rollers are clean and dry, disengage wash-up blade and apply either product liberally across the rollers. Let the solutions run in for 2 to 4 minutes, then engage wash-up blade. Apply additional solution for 1 to 2 minutes, and then rinse off with an application of water and presswash.

Product Code: Alkaline Paper Roller Rinse C826; Salt Crystal Remover C825

READ MSDS BEFORE USING THIS PRODUCT

Packaging: 946 ml (1 US Quart) plastic bottle (12 per case) 3.79 Liter (1 US Gallon) plastic bottle (4 per case)

UN1760



SIA STARLETT Bikernieku 121P, Riga LV-1021, Latvia +371 67531070 starlett@starlett.lv www.starlett.lv INT 7/01

